

PARTS LIST

for


MAYTAG[®]

**COMMERCIAL
GAS DRYER**

**MODEL
MLG24PDAXW1**

LOWER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER CABINET AND FRONT PANEL PARTS


For Model: MLG24PDAXW1
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts (Located Behind Toe Panel)	22	3392914	Frame, Window	52	696144	Strike, Door
	W10184580	Installation Instructions	23	3392915	Gasket, Window	53	9742177	Screw
	W10135168	Tech Sheet	24	3394331	Plate Cover (Bottom Exhaust)	54	W10191265	Plug, Hinge Screw
	W10184603	Repair Parts List	25	8564011	Bracket, Switch	55	3390647	Screw
2	3391915	Screw	26	3389249	Nut, "U"	56	W10169687	Harness (Lower)
3	3390663	Screw	27	W10139766	Motor Assembly (60 Hz.)	57	3390735	Seal, Door
4	3391846	Clip, Front Panel	28	W10167613	Wire, Belt Switch (To Protector)	58	3392538	Catch, Door Assembly
5	8564010	Switch, Broken Belt	29	3394341	Pulley 60 Hz	59	W10155571	Switch Assembly
6	697773	Screw	30	W10131172	Belt, Drive	60	W10213202	Handle, Door
7	8310656	Cabinet, Lower	31	3390902	Clip, Door Hinge	61	697215	Panel, Toe (Includes Illus. 34)
8	3392100	Foot, Dryer Plastic	32	W10135695	Bracket, Motor	62	3387561	Clamp-Pipe
9	660658	Clamp, Motor	33	3392186	Washer	63	W10135231	Burner Assembly 60 Hz. (Refer To Pages 10 & 11 For Breakdown)
10	3387374	Spring, Idler	34	693152	Bumper			
11	3389420	Retainer, Idler	35	279731	4"-90 Elbow			
12	693995	Screw	36	697750	Plug-Multivent	64	697441	Valve, Gas (Complete) 60 Hz
13	3388672	Pulley Assembly	37	488729	Screw	65	3387057	Screw
14	3400077	Screw	38	8283298	Jumper, Door Switch	66	98997	Clip
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 15 & 23)	39	W10141380	Bracket, Idler	67	W10212660	Sound Pad, Motor
16	8539892	Wire Motor (To Belt Switch)	40	686590	Ignitor	68	3391943	Boot, Foot
17	8529757	Bracket, Burner	41	3406109	Door Switch Assembly	69	3393657	Belt, Restrain
18	233520	Washer, Thurst	42	W10002600	Screw	70	3405160	Belt, Poly V
19	297092	Clip	43	3393909	Screw	Optional Parts Not Included		
20	690997	Tri-Ring	44	3387242	Seal, Front Panel	Dryer Exhaust Kit (For Side & Bottom Venting)		
21	3389247	Hinge And Pin	45	342055	Screw	71 279818 White		
			46	3388229	Retainer			
			47	W10205622	Inner, Door			
			48	694091	Screw			
			49	W10205649	Outer, Door			
			50	343641	Screw			
			51	W10192882	Upper Front Panel			

CONTROL PANEL AND SEPARATOR PARTS

For Model: MLG24PDAXW1

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL AND SEPARATOR PARTS


For Model: MLG24PDAXW1

(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10167621	Harness, Collar	18	W10133264	Lock Assembly	31	W10165297	Snap Bushing
2	W10139762	Hex Nut, 3/4-27	19	694415	Strain Relief	32	W10131838	Switch, Vault & Service Door
3	3391018	Tie, Cable	20	3400408	Screw	33	8540229	RFI-Filter
4	697776	Screw	21	W10160652	Bracket-Switch	34	8533971	Screw
5	W10140652	Screw	22	W10137319	Bolt, 10-32 x 6.06	35	W10188051	Jumper, Line Filter
6	W10133285	Transformer 120Vac To 22.5Vac	23	W10159849	Collar	36	W10133266	Locking Cam
7	8533971	Screw	24	694018	Cord, Power	37	W10133514	Standoff, Circuit Board
8	W10177242	Hex-Nut 9/32 - 28	25	W10133258	Vault-Body Assembly	38	W10080190	Nut, 3/8-16
9	W10139046	Nut, 6-32	26	W10133277	Membrane Switch Assembly	39	3400000	Screw
10	W10131119	Screw	27	W10130700	Control Board	40	3396795	Cover, Terminal Block
11	W10163677	Plate, Control Mounting	28	3390443	Retainer, Terminal	41	W10140858	Key, Access Door
12	W10131113	Push Button	29	W10130178	Coin-Optic Sensor Assembly	42	W10169579	Kit-Coin Box Security
13	W10135185	Facia Console	30	W10142655	Screw	43	W10133248	Coin Box
14	W10133245	Coin Drop Assembly						
15	W10133268	Cover, Display						
16	W10133280	Switch, Service Access						
17	W10159907	Mounting Strap Assembly						

UPPER CABINET AND FRONT PANEL PARTS

For Model: MLG24PDAXW1
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER CABINET AND FRONT PANEL PARTS


For Model: MLG24PDAXW1
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3390663	Screw	29	3394341	Pulley (60 Hz.)	59	3387057	Screw
2	3391915	Screw	30	W10131172	Belt, Drive	60	W10213202	Handle, Door
3	8539892	Wire Motor (To Belt Switch)	31	3390902	Clip, Door Hinge	61	697215	Panel, Toe (Includes Illus. 33)
4	3400077	Screw	32	W10135695	Bracket, Motor	62	3389351	Top (Upper)
5	W10155571	Switch Assembly	33	693152	Bumper	63	3391018	Tie, Cable
6	697773	Screw	34	279731	4"-90° Elbow	64	W10117347	Cotter Pin
7	3978859	Cabinet (Upper)	35	697750	Plug-Multivent	65	W10135231	Burner Assembly 60 Hz. (Refer To Pages 10 & 11 For Breakdown)
8	W10212660	Sound Pad, Motor	36	3392186	Washer			
9	660658	Clamp, Motor	37	488729	Screw			
10	3387374	Spring, Idler	38	8283298	Jumper, Door Switch	66	697441	Valve, Gas (Complete) 60 Hz.
11	3389420	Retainer, Idler	39	W10141380	Bracket, Idler			
12	3392915	Gasket, Window	40	343641	Screw			
13	3388672	Pulley Assembly	41	3406109	Door Switch Assembly	67	3387561	Clamp, Pipe
14	693995	Screw	42	W10002600	Screw	68	3393909	Screw
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 12 & 15)	43	3389233	Bushing	69	686590	Ignitor
16	8564010	Switch, Broken Belt	44	3387242	Seal, Front Panel	70	98997	Clip
17	8529757	Bracket, Burner	45	342055	Screw	71	3391846	Clip, Front Panel
18	233520	Washer, Thrust	46	3388229	Retainer	72	689172	Foot, Dryer Plastic
19	297092	Clip	47	W10205622	Inner, Door	73	3393657	Belt, Restrain
20	690997	Tri-Ring	48	694091	Screw	74	3405160	Belt, Poly V
21	3389247	Hinge And Pin	49	W10205649	Outer, Door			
22	3392914	Frame, Window	50	W10191265	Plug, Hinge Screw			
23	3979115	Bracket, Angle	51	W10192882	Upper Front Panel	Optional Parts Not Included		
24	3394331	Plate, Cover (Bottom Exhaust)	52	696144	Stike, Door	Dryer Exhaust Kit (For Side & Bottom Venting)		
25	8564011	Bracket, Switch	53	3400523	Screw, Security (Includes Illus. 64)			
26	3389249	Nut, "U"	54	9742177	Screw	75	279818	White
27	W10139766	Motor Assembly 60 Hz.	55	3390647	Screw			
28	W10167613	Wire, Belt Switch (To Protector)	56	W10169686	Harness (Upper)			
			57	3390735	Seal, Door			
			58	3392538	Catch, Door Assembly			

UPPER AND LOWER BULKHEAD PARTS

For Model: MLG24PDAXW1

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER AND LOWER BULKHEAD PARTS

For Model: MLG24PDAXW1
(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	16	W10001120	Nut, 3/8-16 (L.H.)	30	W10049370	Lint Screen
2	8066086	Drum Hole Plug	17	8520836	Bulkhead, Rear	31	487909	Screw
3	8533971	Screw	18	3387459	Washer, Support	32	W10168564	Wheel, Blower
4	90767	Screw	19	8575325	Shaft, L.H. Thread	33	8563758	Door, Lint Screen
5	3394346	Air Duct Assembly	20	690997	Ring, Tri	34	W10131836	Thermostat, 140°F Cycling
6	697813	Seal, Outlet Housing	21	8536973	Roller, Support	35	3387230	Screw
7	697814	Seal, Drum Front	22	3391912	Thermostat High Limit	36	W10135254	Housing, Blower
8	3934666	Nut, 3/8 x 16 (R.H.)	23	8563755	Housing, Outlet	37	8066168	Lint Duct Assembly
9	8066224	Exhaust Pipe	24	3401707	Jumper-TCO High Limit	38	8573824	Funnel, Burner
10	8572105	Clip, Exhaust	25	8318215	Drum Complete	39	338906	Sensor, Radiant
11	3357011	Screw	26	W10219342	Screw	40	W10193019	Thermostat 155°F Electronic
12	8066208	Clip-Spring	27	W10166807	Seal, Drum	41	697693	Baffle, Drum
13	3390647	Screw	28	3394986	Spring, Lint Screen	42	697557	Bulkhead, Front
14	3402841	Lens, Drum Light	29	8573713	Thermal-Cutoff (Includes Item. 22)	43	8563756	Grille, Outlet
15	8578825	Bracket, Drum Light				44	3392519	Thermal Fuse
						45	697770	Seal, Cover Plate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10135231 BURNER ASSEMBLY

For Model: MLG24PDAXW1
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10135231 BURNER ASSEMBLY

For Model: MLG24PDAXW1
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	W10135231	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 10–16 x 1/2
9		Orifice, Burner
	234870	Type 1
	234868	Type 2
10	W10141728	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, 8–32 x 1/2
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	W10110395	Pipe, Gas Supply
22	697441	Valve & Union Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

W10436933 Conversion Kit
(Type 1 and 2)
to Type (4) L.P.G.

BA-156B

OPTIONAL PARTS (NOT INCLUDED)

For Model: MLG24PDAXW1
(White)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Grey

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------